

VAULT 2i

Netwerkstreamer, CD-Ripper
En Muziekbibliotheek

Handleiding Voor Eigenaar

Welkom bij Bluesound, hifi voor de wifi-generatie.

Deze gebruikershandleiding geeft u een uitgebreid overzicht van de Bluesound-speler en zijn eigenschappen. De Snelle Installatiehandleiding die u bij uw speler vindt, helpt u verbinding te maken met het netwerk zodat u muziek kunt afspelen.

LET OP: Er is een betrouwbare verbinding met breedbandinternet vereist om content met hoge resolutie te streamen van muziekdiensten én om uw speler bij te werken. Zonder internettoegang loopt u de luisterervaring mis met alle eigenschappen die uw Bluesound-speler te bieden heeft.

Ga voor meer informatie over uw Bluesound-speler of de BluOS-app naar onze kennisbank op support.bluesound.com

Meegeleverde accessoires



Stereo RCA naar RCA



3,5 mm stereo-miniplug naar
RCA-kabel



120 V netsnoer



230 V netsnoer



Ethernetkabel



Mini-aansluiting naar
Toslink-adapter

- 2 PLAY/PAUSE BUTTON:** This button has multiple functions – a visual indicator of network connectivity and a PLAY/PAUSE button. For a full listing of LED Blink Codes, please see #1 – Blink Codes. For an ungrouped Player, press the button to Play and Pause the stream. If listening to an Internet radio stream, the Pause function will work for 30 seconds. At this point, the buffer is full and the stream will Stop. When a Player is grouped, pressing the PLAY/PAUSE button will Mute that Player while other Players continue the stream. The Player's LED will flash blue when muted.
- 3 +, - (VOLUME):** Toggle either button to vary volume level. Volume level will not change if you press and hold either button.
(+): Increase volume level
(-): Decrease volume level
- 4 PREVIOUS TRACK/NEXT TRACK:** These buttons can be used to go back to the previous track ◀◀ or skip to the next track ▶▶ in your current playlist.
- 5 AUDIO OUT:** Connect to the corresponding analog audio input of an amplifier, receiver or stereo system.
- 6 SUBW (SUBWOOFER) OUT:** A Subwoofer can also be connected directly to the VAULT 2i. Connect SUBW OUT to a powered ("active") subwoofer.
- 7 COAX OUT:** Using a coax cable (not provided), connect one end to the COAX OUT of the VAULT 2i and the other end to the corresponding coax input of compatible devices such as receivers, computer soundcards or other digital processors.
- 8 OPTICAL OUT:** Using a Digital Optical cable (not provided), connect one end to the OPTICAL OUT of the VAULT 2i and the other end to the corresponding digital audio input of compatible devices such as receivers, computer soundcards or other digital processors.
- 9 OPTICAL IN/ANALOG IN:** Using a 3.5mm Stereo Audio Cable (provided), connect one end to the Analog In of the VAULT 2i and the other end to the corresponding analog output of other compatible devices. The source will show as an Analog Input in the Navigation Drawer of the Bluesound app. Using the 3.5mm Mini Jack to Toslink adaptor (included with the VAULT 2i), a digital optical source can also be added. This will appear as Optical Input in the Navigation Drawer.
- 10 TRIGGER OUT:** A 12V DC signal is available using TRIGGER OUT. The 12V DC signal can be used to control or activate other external devices equipped with a corresponding 12V trigger input using a 3.5mm mono audio cable.
- 11 IR IN:** An infrared extender can be connected to allow for programmable learning remotes to control volume and source selection when a VAULT 2i is stored in a way that the front panel IR sensor is not visible.
- 12 USB (TYPE A):** Connect a USB mass storage device or Bluetooth adaptor to the USB input. Typical USB mass storage devices compatible with the VAULT 2i include portable flash memory devices and external hard drives (FAT32 formatted).
- 13 LAN PORT:** To setup the VAULT 2i, a LAN port for a wired ethernet connection is required. Using the Ethernet cable provided, connect one end of the Ethernet cable to the LAN port of your wired Ethernet broadband router and the other end to the VAULT 2i's LAN port.
- 14 SERVICE:** Use the SERVICE port in conjunction with USB (Type B Mini) to initially load firmware on the Player. This is not for consumer use. Only Authorized Bluesound Service personnel can access this USB port and SERVICE control button.
- 15 AC MAINS INPUT:** The VAULT 2i comes supplied with two separate AC power cords. Select the AC power cord appropriate for your region. Before connecting the plug to the wall outlet, connect firmly the other end of the AC power cord to VAULT 2i's AC Mains input socket. Never force the plug into a wall outlet. An adaptor may be necessary in certain regions. Always disconnect the plug from the wall outlet first, before disconnecting the cable from the VAULT 2i's AC Mains input socket.
- 16 FRONT PANEL HEADPHONE JACK:** A 3.5mm headphone jack is located on the front of the VAULT 2i.

WAARSCHUWING

ZO ZET U DE SPELER TERUG NAAR FABRIEKSINSTELLINGEN. ALLE AANPASSINGEN WAARONDER DE CONFIGURATIE VAN HET WIFI-NETWERK, HET DELEN VAN BESTANDEN EN OPGESLAGEN AFSPEELLIJSTEN ZULLEN VERLOREN GAAN. U ZULT DEZE NA VOLTOOIING OPNIEUW MOETEN INSTELLEN. DIT PROCES WORDT ALLEEN AANBEVOLEN ALS UW SPELER NIET FUNCTIONEERT EN UPGRADEN VAN FIRMWARE VIA INTERNET IS MISLUKT. NEEM VOOR VRAGEN OF ZORGEN CONTACT OP MET EEN BEVOEGDE BLUESOUND-KLANTENSERVICEMEDEWERKER VOORDAT U DOORGAAT!

Stappen voor terugzetten naar fabrieksinstellingen:

1. Haal de stekker van de speler uit het stopcontact.
2. Wacht 30 tellen.
3. Steek de stekker vervolgens weer in het stopcontact.
4. Zodra het led-lampje rood wordt, houdt u de AFSPELEN/PAUZEREN-knop of FUNCTIE-knop ingedrukt. Het led-lampje zal onmiddellijk groen worden en daarna weer rood. Blijf de knop gedurende 30 tellen ingedrukt houden.
5. Na 30 tellen zal het led-lampje rood knipperen. Laat nu de knop los.
6. Alle aanpassingen aan de Bluesound-speler worden verwijderd en de Bluesound-speler is nu teruggezet naar de fabrieksinstellingen.

NOTA BENE: Als u uw vinger van de AFSPELEN/PAUZEREN-knop of FUNCTIE-knop haalt VOORDAT het led-lampje rood knippert, zal het terugzetten naar fabrieksinstellingen worden geannuleerd en blijft de speler in upgrade-modus. Begin opnieuw bij stap één om de speler terug naar fabrieksinstellingen te zetten.

Als het terugzetten naar fabrieksinstellingen is geslaagd, keert de speler terug naar Hotspotmodus (draadloze verbinding: het led-lampje wordt effen groen). Als de speler via een bekabelde ethernetverbinding met het netwerk is verbonden, zal deze verbinding maken alsof het simpelweg een nieuwe speler is (het led-lampje wordt effen blauw).

BLUESOUND®

© Bluesound International. Bluesound, het gestileerde woordmerk 'B'-logotype, de zin 'HiFi for a wireless generation', VAULT 2i en alle andere productnamen en slogans van Bluesound zijn handelsmerken of gedeponeerde handelsmerken van Bluesound International, een onderdeel van Lenbrook Industries Limited. Alle andere logo's en diensten zijn handelsmerken of dienstmerken van hun respectieve eigenaars.